



Installation Instructions

Always Check Stock # and Color Before Starting Installation



**1994-99 Toyota Celica
TY 7710 Top
ST11 Blk/Blk Stayfast or Topline Material**

TY7710 ST11
Black/Blk
Stayfast 10 10



DATE: 11/01 (MAKE LABELS) ONLY

TY7710 ST11

1995-98 Toyota Celica Asc

DATE: 11/01

(MAKE LABELS) ONLY



Electron Top Mfg.



Staple the bottom of the rear window putting the line at the upper edge of the trim stick.



Staple the rear quarter pads to the trim stick.



Staple the rear bow listing making sure that the top is centered on the rear bow.



Staple the rear quarters starting at the front of the quarter putting the line at the upper edge of the trim stick and working your way around towards the window.

Electron Top Mfg.



Staple the front corners of the top.



Glue the rear channel flaps to the C pillar post.



Put back on the channel rubbers.

Electron Top Mfg.



Passengers side rear quarter view.



Drivers side view.

